

This products absorbs and converts solar energy to charge the batteries during the day. At dusk it automatically turns on. The number of hours the light illuminates depends upon your geographical location, weather conditions and seasonal lighting availability.

BEFORE YOU INSTALL:

Since this product may be in a sealed carton for a prolonged period of time before purchase, any charge in the batteries has likely dissipated. Follow these two simple steps below prior to installation to ensure this solar product will function properly.

- Expose the unit facing the sun for a full day (24 hours). If weather conditions don't permit this, place
 the product with the solar panel 12"-14" (350mm) away from a strong halogen spotlight (approx.
 300W) for 2-3 hours. Inspect the product periodically to ensure it does not get too hot and become
 damaged from the spotlight.
- Once the product is charged, cover the solar panel (photo sensor) completely with your hand or enter a dark room to ensure it illuminates in the absence of light.



- 1. Choose an outdoor locations with full/direct sunlight.
- 2. Install multiple product 6ft. (2m) apart and as per instructions below. **WOOD SURFACES:** Use an appropriate wood screw for the application.

MASONRY: Place the product in the desired position and mark the screw hole locations on the mounting surface. Drill the masonry surface with a masonry bit for the desired masonry screw or anchor size to be used.

METAL: Place the product in the desired position and mark the screw hole locations on the mounting surface. Drill the holes in the metal surface to accept the size and type of metal screw desired.



- 1. Unscrew the top cap with solar panel.
- 2. Unscrew the two screws holding the circuit board in place.
- Replace the battery with AAA (triple A) rechargeable Ni-Cd or Ni-MH batteries.
- Reinstall the circuit board and screw the solar cap on snugly to properly seal your light.

CHANGING LED ILLUMINATION COLOR:

There is no need to replace LED's with the Solar Piling Cap Light to change colors. Remove the threaded solar cap and flip the current color switch to the "OFF" position. Flip the appropriate switch to the "ON" position as per the chart to

illuminate the desired color LED. **Note:** Only one (1) color should be in the "ON" position at any given time. More than one color in the "ON" position may result in product failure.

IM	ы	NR.	ТΛ	NI	r
ши			תו		١.

Solar Piling Cap Lites are NOT intended for use as navigational lighting.

SWITCH	COLOR	
1	WHITE	
2	GREEN	
3	BLUE	
4	ORANGE	
5	YELLOW	
6	RED	



